


Quick Installation Guide


External Carrier and 68-pin drive

DK31/32CJ-MW



1. Do not use the Auxiliary Connector (C5)
2. Connect the ID cable to ID0-ID3
3. Connect the LED to pins 17-18.

DK32DJ/EJ-MW



1. Do not use the Auxiliary Connector (4)
2. Connect the ID cable to ID0-ID3
3. Connect the LED to pins 21-22